TP410 WEIGHING PALLET TRUCK





TP410 VERSIONS



ACCUMULATION
ZERO
TARE
BRUTO/ NETO
FUNCTION PIECES COUNTING
FUNCTION WEIGHT CONTROL



Weight tare indicator with a memory to up to 400 item 1, 400 item 2 and 10 prefixed tares.

The introduction of the details of the product can include code, description, tare, EAN code and the characterization of the product is according to its operating platform (weight, target weight or unit weight for the piece-counting function).

The introduction of the details of the customers can be done by code, description or pretare. This series also includes the possibility to do lists of stored weights according to detail or filtered according to customer, product or date.



PIECE COUNTING

This function allows the user to count the pieces which have been loaded on the platform according to the unit average weight PMU which has been scheduled previously.

It also allows the counting of the PMU according to the amount of pieces which have been loaded..



TOTALISATION

This function allows the user to do the addition of the weights accumulated in the memory and shows the total number of weights.



CHECKWEIGHER

The weight indicator GI400 includes the mode checkweigher or pass-not pass.

It can manage automatically up to 4 zones using weight limits for each one of them. By selecting the desired weight, the indicator allows the user to choose superior or inferior limits through value or percentage.



TP410

#Code		Description	Capacity (kg)	Readout (kg)	€
290001		TP410 painted steel with digital indicator LCD	1000/2000	0,2/0,5	
290002	M	TP410 painted steel with digital indicator LCD	1000/2000	0,5/1	
290003		TP410 painted steel with digital indicator LCD + Printer	1000/2000	0,2/0,5	
290004	M	TP410 painted steel with digital indicator LCD + Printer	1000/2000	0,5/1	

OPTIONS

#Code	Description	€
220021	Communication board Wi-fi for TP410	
220008	Additional plate ALIBI/DSD memory	

